



## Change the Name of your Wireless Network (SSID) On a Comtrend Router

1. Open a browser (Internet Explorer, Firefox, Google Chrome, or Safari) on your PC or Mac.
2. Type **192.168.5.1** into the address bar and click “Enter”




3. Enter the username and password and click “OK”

User Name: **root**  
Password: **12345**



4. Once logged in click on “Wireless” and change the **SSID** to your desired name.



5. Click on “Apply/Save”